



User Manual



May 2015
Rev. fw 3.2

Table of contents:

- 1. Introduction..... 3
- 2. Product Features 4
- 3. Usage Scenarios 5
- 4. Package Contents 6
- 5. Hardware Overview 7
- 6. Remote Control 8
- 7. Starting the FrameXX..... 9
- 8. FrameXX Menu 12
- 9. Remote access – Direct (intranet) 30
- 10. Remote access – CONTROL cloud 38
- 11. Playlist usage 49
- 12. Special system files..... 51
- 13. HOME – manual monitor adjustment 52
- 14. Limited warranty 53



1. Introduction

Thank you for purchasing FrameXX – high-performance and low-cost digital signage platform with LAN/internet connectivity that allows you to play multimedia content in Full HD quality.

The user interface is easy to understand and no additional software is required. Simply insert the memory card or set-up network connection and you can play the media files from the selected source.

There are the following models available – **FrameXX HOME/2**, **FrameXX HOME/2-XL**, **FrameXX HOME/2-XXL** and **FrameXX SIGN/2**.

FrameXX HOME is a standalone device with very rich digital photoframe features. It is based on a fullHD 32", professional industry class AMVA panel, and features a wooden frame in size 79x48cm. The construction allows you to replace the wooden frame (standard colours – black, natural wood, white, cherry brown) very easily and customize to a requested design.

Frame HOME-XL is based on a 46" professional industry class AMVA panel, with dimensions of 115x71cm.

Frame HOME-XXL is based on a 55" professional industry class AMVA panel, with dimensions of 139x86cm.

FrameXX SIGN contains identical engine&software as FrameXX HOME, the only difference is in the missing display, which allows the device to be connected to any display device with an HDMI input (up to 4K video resolution). It is mostly used in the Digital Signage industry, however it can also be connected to large flat TV devices at home.

For presentation from local or internal memory there are no additional settings necessary, for presentation from intranet or internet (e.g. Flickr, Dropbox) you have to set up a wireless connection with credentials. The FrameXX devices are ideal for advertising, retail displays, museum exhibits, galleries, home usage and other applications. The possibility of remote content management via **FrameXX CONTROL** cloud and automatic slideshow synchronization with remote source also makes it eligible for maintenance and remote usage. Just switch it on and the FrameXX can start the show automatically. You can use built-in advanced Timers or any simple programmable outlet timer to switch it on and off at any favourite time



2. Product Features

- Wireless multimedia device WiFi-N / LAN (HOME-XL, SIGN) connectivity
- Supports different multimedia sources
Internal memory, USB/SD, LAN (SMB/UPnP), Internet, Flickr, FTP, Dropbox, websources...
- Photo slideshow with music in the background
- Supported formats
VIDEO (MPEG4, MKV,AVI,TS,VOB,MPG, MP4, MOV,3GP...),
PICTURE (JPG,BMP,GIF,BMP,TIFF)
WWW (ASCII text with filename ABC.www. Each line contains 1 www address. Time delay between lines corresponds to the current Delay valid for Slideshow.
PLST (Playlist file, ASCII text with filename ABC.plst. Each line contains command for 1 item within Slideshow)
IFR system command file (for internal memory operations - copy, delete...)
- Built-in HTML5 browser (http+https) able to run in Slideshow or standalone
- Built-in Youtube separate module (not able run in Slideshow)
- Mix content play (Photo/Video/WWW)
- Autoplay for all media formats and all sources
- Slideshow of all sub-directories
- Landscape / Portrait presentation mode
- Multiple transition effects, flying text, fixed image (multi-layer system)
- Remote Slideshow synchronization/update over LAN or internet
- Full HD resolution (HOME), 4K output (SIGN) with HDMI output, portrait/landscape, 50/60Hz modes
- Multiple languages
- Centralized remote surveillance of running devices (CONTROL cloud)
- Fanless design (silent operation)
- and more.....

FrameXX User Manual v. 3.2



3. Usage Scenarios

- Maintenance and advertisement in public spaces (shops, hospitals..).
- Operation with remote control over internet (can be used by non-IT users e.g. older parents) by other distant people (family). Family can then change the content of Slideshow by adjusting their own Flickr account , remote SMB, FTP, Dropbox or CONTROL cloud.
- Connection and all content will be synchronized. Therefore only ON/OFF can be required by local user.
- Presentations (with description) controlled and monitored from one place.
- Instant home direct presentation of ALL photos/videos stored in NAS (the most safe and suitable place for photo/video)



4. Package Contents

FrameXX HOME/2

1. FrameXX HOME device
2. Remote Control
3. User Manual
4. “Invisible” transparent extension 3m cord

FrameXX SIGN/2

1. FrameXX SIGN device
2. Remote Control
3. External Infra sensor
4. HDMI thin 1,5m cable
5. Metallic holder
6. User Manual
7. Power Adapter



5. Hardware Overview

FrameXX HOME/2

2x USB slot: can be used for USB memory, USB keyboard or USB mouse (faster data input)

WiFi antenna: non removable antenna for WiFi 802.11 b/g/n connectivity, 2.4/5GHz modes

Audio out (L+R), cinch connection

Audio in (L+R), cinch connection

LAN RJ-45 port: HOME-XL/XXL only

IrDa built in receiver

FrameXX SIGN/2

2x USB slot: used for USB memory, USB keyboard or USB mouse , USB numbering depends on the insertion order, not USB slot position.

1 x SD slot: for memory card

WiFi antenna: non removable antenna for WiFi 802.11 b/g/n connectivity, 2.4/5GHz modes

LAN RJ-45 port: wired Ethernet 10/100Mbps connection (RJ45 connector)


HDMI out: 4K video+audio output (connected to monitor/TV)

DC in: DC input from Power adapter (use only supplied adapter)

External Infra sensor connector: 2.5" jack connector for external IrDA sensor



6. Remote Control




The Remote Control is powered from 2x AAA 1,5V batteries.



7. Starting the FrameXX

Powering FrameXX

1. Connect to power socket, eventually use HDMI video cable to connect FrameXX Sign and TV or monitor.
2. With HOME, check if needed to use manual switch next to power cord, then use RC and power the device.
3. If you want to present from local memory, insert the memory into the USB or SD slot. All slots are hot-plug, so you can insert the memory while the device is running. *(if you want to present from internal memory, it is needed to first copy files there)*



Main Menu

The main screen will show up after power on by default.
(if you turn Autostart ON (not default), the Slideshow will start automatically).

Main screen layout consists of 4 regions:

1. FrameXX Menu

Located here are 3 submenus – FrameXX application options, Timers and System Menu (settings of system, system maintenance, Youtube..)

2. Main Menu

Memory – internal memory on board. This location is handled via *.ifr system files (explained later) or via browser (direct Web access)

Memory card slots




1xSD (SIGN), 2xUSB 2.0.,available/inserted memory is highlighted
Network media sources for presentation:

LAN

Network Samba server (standard network storage used in Windows, NAS)

UPnP

Any available UPnP/DLNA media source within local network



Flickr

World's #1 photo internet cloud storage for your media files (www.flickr.com)

Dropbox

World's #1 independent cloud service

WWW – html page as defined in WWW option

FTP – server accessible via File Transfer Protocol

History – list of recent Slideshow media sources with possibility to run any address (this list makes the future slideshow from different sources very easy to access quickly, it works like “bookmarks”). The most recent (top line) is the active source for Autostart.

Note:Manual presentations are not stored in the History list, except for www and plst files.The selected Slideshow runs according to the current device settings (Delay, Transition, Recursion...).

There is a special History item as default that allows you to quickly access the FRAMEXX FLICKR DEMO account, it cannot be deleted.



Start Slideshow – starts the Slideshow (available in bottom bar as well)

3. Folder selection

Browsing and selection of folders and files.

Note: when cursor is located in Folder selection, you can get promptly to the Main Menu with Left arrow and to Recursive & Start Slideshow with the Right arrow. Fast browsing available with Page UP/Down buttons on remote control.

4. Recursive & Start Slideshow

Marking the “Recursive” option allows you to include all files and subfolders in Slideshow.

The Slideshow starts according to the selected parameters.

The Slideshow can be Paused anytime (OK) and then continued (OK) or if picture rotation needed, in Pause mode press arrows left/right (90degrees CCW/CW rotation).



8. FrameXX Menu

System Menu is accessible by cursor buttons (3 dots in upper right corner):

Status

General information about current FrameXX device.

Youtube

This is separate Youtube module. In older systems it is first necessary to install (framexx-youtube.apk, available under Download section at www.framexx.com)

Internet update

FrameXX checks availability of new firmware version on the Internet.

Changelog

Here the info and history of all firmware revisions appears.


Note – as this file is downloaded from server, internet connection is required.

Display

Located here are display settings as well as the Miracast function. It is possible to select resolution (up to 4K/30fps), display orientation (landscape/portrait), 50/60Hz modes, adjust picture position/size (20 levels) and use Miracast module (Wifi video/audio transfer from PC/tablet/phone to FrameXX)

Note:

FrameXX has default 720p output resolution for SIGN and 1080p for HOME. If your TV/monitor allows using of higher resolution, please set it accordingly (4K, full HD=1080p, HD-ready=720p). When selecting a new mode, one more step is required to confirm visibility of the new display mode. If nothing confirmed, display mode will revert to previous resolution within 15 sec. You can also make a display position and size adjustment (each output resolution requires separate display adjustment). For certain



special conditions (TV video record..), there are 50Hz modes available (if you do not know why you should use 50Hz, then use 60Hz settings)

Date/Time

Settings of current Date/Time, the highly recommended setting is Automatic (requires internet connection). **Don't forget to set your GMT zone.**

WiFi

WiFi is enabled by default and it is necessary to set up your WiFi connection.

Note: For FrameXX SIGN and HOME-XL/XXL the RJ-45 slot can be used as well, default settings is DHCP automatic configuration. It is always better to use cable LAN connection, if not possible, we recommend to use 5GHz Wifi band.

Device system

Located here are full system settings. Please be careful, some settings can even delete configuration or terminate device operation. You must always know what you configure.

Timer Menu is located under clock symbol.

Timer options

Timers allow you to define when the device will be switched ON/OFF.

When Timer scenario is completed then it appears in the basic Timers list.

Note: Timers can be set from browser Web access or via CONTROL cloud as well. Don't forget to set the GMT zone used in CONTROL cloud account profile. Device consists of RTC (real time clock with battery) therefore internet NTP synchronization is optional only.



FRAMEXX application options

Delay

Time between the consecutive photos during Slideshow (Range 1sec – 100hrs)

Layout

Layout of the Slideshow defines the design of current Slideshow.

Following options:

Fullscreen Dissolve (default)

Fullscreen Fade in/out

Four regions – photo can be placed variably into different regions (various size)

Four regions centered – photos are placed equally into 4 regions

Random photo placer

Four corners

Single fly by – single photo will come from left side moving

Double fly by

Random fly by

Single fly down

Single fly up

Transition

Here it is possible to define the style of transition between 2 items in Slideshow.

The following options are available:

Dissolve

Fade in, fade out

Zoom in

Zoom out

Slide left

Slide right

Random

None

Zoom effect

Greyscale effect

Page turn

Blinds

DISPLAY OPTIONS	
Delay	
Layout	Slideshow layout
Transition	Select transition between two photos.
Background color	
Aspect ratio	Fix picture if different aspect ratio than screen
Photo order	The order in which the photos will be shown
Start opacity	Photos can appear slowly. If required to display immediately, set Start opacity to max
End opacity	Photos can disappear slowly. If required to dismiss immediately, set End opacity to max



Zoom in effect

Background color

It defines colour on the border outside of the active Slideshow item.

Aspect ratio

Selection of how the screen will be filled out with current picture

There are 3 options

Default – photo is displayed with exact aspect ratio as original

Max visible (Aspect ratio preserved) – Photo will use maximum of screen with original aspect ratio. The photo will have mostly border region removed, as the screen ratio is 16:9 and photo will not cover full screen

Max visible (Aspect ratio changed) – photo will cover full screen and is adjusted to the screen aspect ratio (therefore not original). Photo is usually heavily modified.

Photo order

It defines the order of how the files and folders are displayed in Slideshow (it appears only during Slideshow)

Random selection – each presentation is unique as the order will be random

Alphabetical order – It works for all items (Folders & Files)

Timestamp order – order according to time information

Alphabetical order (keep folder structure) – useful for “Recursion ON”. The order will follow first the directories, and then the files.

Start opacity

It defines how slowly/quickly new photo will be displayed (fade-in). Range 0-255, value 0 means slow appearance, value 255 is instant photo appearance. Usually it is not needed to change this value.

End opacity

It defines how slowly/quickly current photo will disappear (fade-out). Range 0-255, value 0 means slow fade-out, value 255 is instant fade-out. Usually it is not needed to change this value.

Banner options

Enable/disable vertical banner of the display on the right side.

There are following submenus

- **Horizontal banner top**
- **Horizontal banner bottom**
- **Vertical banner left**



- **Vertical banner right**
- **Text speed**
- **RSS location**
- **Background color**
- **Text font**
- **Color font**
- **Banner over slideshow**
- **Banner size**
- **Banner item position**

Horizontal banner top/bottom

Vertical banner left/right

Enable/disable banners around the display.

There are the following options

None – banner disabled

Fixed image (Device name.JPG) – it displays a single image during complete Slideshow. This file must be in JPG or PNG (this is important when identical filenames exist) format and placed in the top directory of the Slideshow. Image files must carry identical filename as “Device name” – e.g. iframe.jpg

Note: If Slideshow runs from Flickr or website (not possible to simply put Fixed image to that location), then Device name.JPG file must be stored in root of MEMORY.

If PNG saved with transparency option and a Banner over the Slideshow is enabled, then it is possible to place image as a transparent logo into pictures/videos in Slideshow.

Text from file (Device name.TXT) – it displays the text from ASCII text during complete Slideshow. This file must have TXT extension placed in the top directory of the Slideshow with identical name as “Device name” – e.g. iframe.txt (if Device name is “iframe”)

This option is mainly suitable for horizontal orientation of FrameXX device.

Note: If Slideshow runs from Flickr or website, then Device name.JPG file must be stored in root of MEMORY.

Clock – it displays an analogue clock

Photo information – if there is an identical TXT file as current photo (e.g. pic1.jpg and pic1.txt), then this TXT file is displayed with the photo.

If there is no such TXT file, the filename and date of the current photo is displayed. This option is suitable for horizontal orientation of FrameXX device.



RSS – the RSS feed is taken according to the RSS location address settings .

Text speed

If displayed text is longer than screen, then it starts scrolling. Here it is possible to select speed of scrolling

Very slow

Slow

Normal

Fast

Very fast

RSS location

This field defines the RSS feed address when RSS option for banner is selected. If requested to display more RSS feeds, each RSS address must be separated by a comma “,”.

It is possible to define up to 4 various RSS feeds for all Banners.

RSS feeds are displayed in order corresponding to current banner settings (in given order – HBT, HBB, VBL,VBR).

Example:

Horizontal banner top – RSS

Horizontal banner bottom – RSS

RSS : http://RSS_feed_1, http://RSS_feed_2

Background color

Here it is possible to define background of enabled banner.

Available in the following colours:

Transparent (use with Banner over Slideshow enabled)

Black/Blue/Dark gray/Gray/Green/Light gray/Magenta/Red/White/Yellow

Text font

Here it is possible to choose from more than 20 various fonts (normal, bold, italic..)

Color font

Font settings for text banner are available in the following colors:

Black/Blue/Dark gray/Gray/Green/Light gray/Magenta/Red/White/Yellow

Banner over slideshow

Banner will be displayed INSIDE of Slideshow items, therefore it keeps original screen resolution and aspect ratio.



Banner size

Banner size can be defined in 6 levels. Percentage number displays exact aspect ratio of reserved window for Banner.

Example – level 2 (20%) – window has aspect ratio 100:20 (for horizontal banners), respective 20:100 (for portrait banners).

For complete window filling the aspect ratio is important, not the resolution (auto-adjustment is processed) , image for banner in Full HD is 1920x384, HD ready 1368x273.

Banner item position

Left/Top

Center (default)

Right/Down

File mask for Slideshow

Here it is possible to select (a mask) what types of files are visible in Slideshow .

Show photos

Show videos

Show www lists (.www)

Show playlists (.plst)

The **WWW file** is plain ASCII text with filename ABC.www (using Notepad.exe in Windows means Saving with ANSI Code page, otherwise saving in Unicode or UTF-8 will result in added reserved bytes in the header of the file, which could cause problem in processing of the first line). Each line contains 1 www address; it is possible to use short names (w/o http or www). Time delay between lines corresponds to the current Delay valid for Slideshow.

Example:

www.ibm.com

<http://www.framexx.com>

<http://www.framexx.com>

This causes framexx website to be refreshed according current Delay value.

The **PLST file** (Playlist file) is plain ASCII text with filename ABC.plst. Each line contains full command for one item within Slideshow. Full details on PLST specification in Chapter 8 – Default settings

Date mask for Slideshow



Here it is possible to select what files are visible within Slideshow, based on Date information.

Activate mask type (Disabled, Fixed date, Fixed period)

Fixed date (the Slideshow will include files from present day to the Fixed date as the oldest)

Fixed period (the Slideshow will include files within this period only.

Example – when set 7days, then the Slideshow displays files only from the last 7 days. When Reload is enabled, then every new day the files beyond the 7 days limit will be excluded from Slideshow and the new files from current day will be loaded automatically)

Note – please check the current date settings (visible in System Menu – Date&Time or here in Options – Date mask for Slideshow).

Date format

Selection of 12hr/24hr time format

Enable portrait mode

If selected, all photos are displayed in Portrait mode orientation, not important what orientation info is stored in EXIF flag . It is suitable for Slideshow of portrait photos.

Enable external video engine

It enables SW decoding of video files. This is very special option, it is usually best to keep it unchecked as the device has built-in internal powerful 8-core HW GPU (graphical processing unit).

SW video decoding consumes a lot of processor computing power and with high-quality (or high frames rates) video files the decoding cannot be processed correctly. It can result in slow choppy video playback

This option has the following advantages

- seamless transition between video files
- more fluent RSS/TXT feed
- wider video codec compatibility

Manual mode if single file is selected

Manual mode is started if a single file is selected. If enabled, video is played in a loop, picture waits until remote control is pressed. If disabled, a standard (automatic) Slideshow starts from the selected file.

OPTIONS - Network options



LAN server

As the standard LAN item in the menu can search/browse just within the current local LAN subnet, these settings are required in the following cases

1. Local LAN server is located in the same subnet. Then this option will speed up the availability of this server (typically – 1 server in home network)
2. Local LAN server is located in another subnet. Then this option is the only way to reach such server (standard LAN/uPNP search/browse can work in single subnet only)
3. Remote LAN server is located anywhere on the internet. This option is the only way to reach this server.
(Note: When used for accessing of remote SMB server, it is often necessary to provide/enable the SMB access on remote router/firewall. Standard open ports required for accessing of the Samba shares are 139 and 445, FTP protocol requires port 21.

Fixed server

IP address of LAN server

Username

Password

Domain (optional)

FTP server

FTP server

IP address of FTP server used for browsing via FTP option in Main Menu.
*When requested to use special FTP port (other than 21), use syntax
IP_FTP_SERVER:port*

FTP user

FTP password

Web browser options

WWW starts with

Homepage (as defined in WWW address)

Empty

Using WWW menu item in Main Menu will bring up an empty screen. Within the browser, using the Menu key on the Remote Control will open



Bookmark Submenu, where it is possible to store favourite websites or load website from this list.

Other options to run html pages (even during Slideshow as standard item) are by using of **www file** from main browser.

WWW address

This URL address of the html page will be used with WWW menu item in Main Menu (e.g. html://www.framexx.com, www.framexx.com, framexx.com)

Preferred WWW desktop version

This option enables display of the html page in full desktop mode as preferred.

Enable UPnP

It enables UPnP/DLNA networking browsing from visible/invisible menu item in Main menu.

Flickr

Flickr account name

FrameXX supports direct access to Flickr accounts.

To be able to view a Slideshow from Flickr, it is first required to enter the Flickr web address of the desired Flickr Photostream.

Note: According to the latest changes in May/2014 regarding Flickr user account policy, it is possible for Free account there with up to 1TB free space, up to 60 collection, max 200MB/1 picture, max 1GB/1 video (up to 3mins duration). Complete info can be found at

<http://www.flickr.com/help/limits/#150470666>

To be able to provide the photos for FrameXX, it is required to create unique Flickr web_address (You – Your_account – Your Flickr web address) – e.g. <http://www.flickr.com/photos/naviion/> . In this example, the word “naviion” is the only unique web_address and must be entered in the “Flickr account name” dialog.

This web_address must be entered prior to entering Flickr from Main Menu.

Flickr quality

It defines quality of downloaded/presented pictures from Flickr.

There are 3 levels

Low = approx VGA quality

Medium = approx HD ready quality

High = approx Full HD quality



Since Flickr is providing various formats from the original pictures immediately on the fly upon request of FrameXX, the exact format/aspect ratio and resolution is based on original files.

Note: Please be aware that this selection has significant impact on volume of transferred data from server to FrameXX device.

Enable reload

Synchronization function, for LAN/Flickr/UPnP Slideshow..

It enables/disables reload/synchronization of the current running Slideshow with the remote original Slideshow source. Upon content change on remote server location, the current running Slideshow will be adjusted automatically.

Reload interval

It defines interval between 2 consecutive controls (synchronizations) , if there is any change between currently running Slideshow and source files on the original server.

Range 1sec – 100hrs.

Enable reload must be checked first.

Monitoring / Remote control / Proxy

FrameXX account

It defines the FrameXX account on CONTROL cloud (where device is reporting/monitoring to).

Example of typical scenario:

-Create a FrameXX account on CONTROL cloud (control.framexx.com).

-Enter created account name in the device (into this field)

Note: First, an account on FrameXX CONTROL cloud must exist.If not, entering FrameXX account in the device will fail.

As a result, you can then follow all FrameXX devices (separated by unique Device_names – see Device name item) that belong to this account (grouping) on CONTROL cloud (control.framexx.com).

Here you can find all information about running devices, as well as full control, history report , etc..

More info in CONTROL cloud chapter.

Monitoring



It enables/disables monitoring in CONTROL cloud.
When unchecked, device does not appear in CONTROL.

Remote control

It allows remote control of the device from CONTROL cloud. Level of remote control depends on current CONTROL license (Free or Pro).

Remote control settings

FTP server

This remote FTP server is used for CONTROL cloud file and playlist storage.

If default, then the device is controlled via system FTP account.

Default FTP server settings support only the device remote control. It does not support file operation, therefore it is not possible to use dedicated FTP storage space and Playlist creator wizard cannot work.

We strongly recommend that you use your own dedicated FTP server to enhance operation security and consequently, open access with any standard FTP client for handling of files.

Note: FTP server and the following credentials must correspond to the CONTROL cloud account settings !

Selected FTP server must allow simultaneous access for the number of users (best is without limitation) , some basic public FTP servers do limit to concurrent connection for 1-3 users which cannot work with frameXX devices.

FTP user / FTP password

Credentials for remote FTP server.

If server is Default, then keep this untouched (default)

Remote control interval

There is a delay between two consecutive device controls on CONTROL cloud if any new command has been left for the device by the user.

Default is 20 sec, after setting up the device communication with CONTROL cloud, it is recommended to increase the interval (to lower server load).

Include files and folders

A control XML file generated by the device for remote communication with CONTROL cloud will contain full file listing of all local storage locations (Memory, USB, SD). It can heavily increase data traffic (due to high number files and folders). However it allows, to remotely select any file(s) or folder(s) to be started, deleted, etc...



SOCKS Proxy Settings

This option enables FrameXX to work in corporate environments where all internet traffic is directed via Proxy server.

Proxy server

Proxy server name

Proxy port

Proxy server port

Proxy user

Proxy password

Developer settings

The following options are used in very special cases, any change in these fields will interrupt device communication to standard CONTROL cloud.

Monitoring server

For special instances, when user requests use of his own CMS system, it is possible to redirect all monitoring (LOG) communication from the FrameXX system server to a separate FTP server.

Syntax is – <ftp://user:passw@server> [/folder]

Compatible Log

This option will enhance time precision information by adding seconds in the monitoring LOG file. As default CONTROL cloud does not support this format, use of this parameter must be processed by separate procedure.

OPTIONS - Audio options

Background music

It enables MP3 music playback during the Slideshow.

The MP3 file(s) must be placed in the top directory of the current Slideshow.

There are the following options

Off – music is not played

Sequential order – music files are played in the order exactly as displayed

Shuffle – music files are played in random order



Note: MP3 files are visible in Folder selection, but cannot be started directly. The visibility is for review of available music files only.

Volume

Range 0-100, can be adjusted during playback from the remote control as well.

OPTIONS - System options

Start Slideshow after reboot

It enables/disables the ability to run the last used Slideshow (top line in History) immediately after restart.

Note: History folder contains just recent Slideshows (starting with Start Slideshow command). Single files or Slideshows started directly from the line of file appearance (Manual mode) will not be saved in History, and therefore cannot be automatically started immediately after reboot.

Copy remote files

This feature enables unique non-streaming functions. First, all requested files for Slideshow are copied to Local memory (MEMORY, USB,SD). Then, the Slideshow is played from this local memory only (therefore no streaming every picture).

This function is very useful for limited internet connection bandwidth or for simultaneously running devices when more video streams could be requested at the same time. In such situations, a Wi-fi router cannot provide sufficient bandwidth.

Important – when the reload/synchronization function is enabled, then upon changes of remote files for Slideshow, the files in the local memory are then synchronized on the background during the running of the Slideshow.

Note: If enabled, when the Slideshow contains a lot of files, it can take a long time at first to copy all the files to the FrameXX local memory.

Copy folder

Selection of the local memory storage folder for copied files (MEMORY, USB, SD)

When Copying remote files is enabled, then each remote Slideshow creates a local copy (in subfolder).



4 locations available – MEMORY (default), SD, USB1, USB2 (very rare case and numbering is assigned upon insertion order – therefore can be used just in case when permanent one USB slot is permanently occupied)

Visible information

Selection of status/progress information displayed on screen.

Enable photo numbering (Total number of photos and current position within Slideshow)

Display progress rotational circle (Show indicator of progress/loading during the Slideshow in the right bottom corner)

Check for update (Check for a system update over the internet. If found, a notification message is displayed in the bottom line (“New firmware available”). Nothing is processed automatically, it is necessary to run the update manually (Internet update from System Menu)

All status information about loading during slideshow
(Enables/disables all progress messages during Slideshow)

Local storage

It enables/disables direct access menu buttons in Main menu.

SD usage is typically disabled for HOME because HOME does not have SD an interface available. Or, it is possible to disable USB2 if just one USB memory will be used.

It simplifies the Main menu and makes operation with the remote control faster (similar to UPnP enable/disable option).

SD enabled

USB1 enabled

USB2 enabled

Device name

Device name is used for

- Use of special IMAGE/TEXT files in Vertical/Horizontal banner
- Remote communication with CONTROL cloud and recognition during reporting and remote control (when enabled)

Default name is FrameXX + WiFi MAC address, and can be changed to any string.



For larger installations, it is advisable to include current location into Device_name, it helps for better orientation on the CONTROL cloud.

Reboot options

It is very practical to restart the device once a day to refresh all internal memory and cache.

Repeated Reboot (Enabled, Disabled)

Repeated Reboot Time

If Repeated reboot is Enabled, then device is restarted every day at this time.

Immediate Reboot

Device is immediately restarted. This function can be accomplished with SIGN device with a long press of ON/OFF button on the device.

Web interface

FrameXX device contains a web server that allows direct access to FrameXX via LAN in any web browser. *Note - any change requires restart of device.*

Enable web interface (Enabled / Disabled)

Web interface port

Default port 8080, can be changed to any value higher than 1024.

To access the device in browser, type in the command line

IP:port, e.g. 192.168.0.100:8080

Username / Password

Default credentials are username: admin, password:framexx.

Language

Selection of requested language (English, German, French, Spanish, Czech, Dutch, Portuguese), English is default.

Load settings

File framexx_settings.xml (placed in root of USB or SD) is loaded into the system. Settings also contain the History.

Save settings

Current device settings are saved in file framexx_settings.xml (placed in the root of USB or SD). Settings also contain also the History.



Clear history

This completely erases the device History bookmark.

Clear Dropbox credentials

As Dropbox is working in a secure mode by supplying encrypted tokens to the host (framexx) device, only once entering Dropbox credentials in the login dialog will it be possible to access the current account.

If you would like to use another Dropbox account, it is first necessary to erase these secure tokens which will allow you to enter new credentials during the next Dropbox visit.

Due to this secure mechanism, Dropbox Slideshows cannot be stored in History bookmark.

Default settings

This option consists of 2 phases that run separately.

1st phase allows to return to factory default settings (it is possible to reject it with NO selection)

2nd phase allows to clear internal memory.

It returns all settings back into factory default settings:

Delay between pictures	
Layout	Dissolve
Aspect ratio	Default
Order of files	Alphabetic
Start opacity	0
End opacity	0
Show numbering	Enabled
Vertical banner	None
Horizontal banner	None
Text speed	Normal
Photo/Video	Photo + Video + www
Date format	dd/MM/yyyy kk:mm
Music	Off
Volume	50
Reload of files	Disabled
Reload check interval	20
Fixed IP	Empty
Flickr account	Empty
Flickr quality	Low
Reboot enabled	Disabled
Folder selection after reboot	Disabled
Copy files before start	Disabled
Path of files	empty
Device Name	FrameXX-[MAC]
Languages	English
Max number of files	20.000



FTP Reporting
FTP account

Disabled
Empty



9. Remote access – Direct (intranet)

Generally, this is direct access within your own network, therefore it is generally expected that all ports are open for communication. Also, this can be used for larger remote installation, but definitely there will be security issues as open ports on remote routers will be needed.

The biggest advantage is direct operation with the device where all commands and reports are processed immediately and sent actively from device back to the PC .

This access relies on **Web interface** settings in Options. By default, communication is opened via port 8080, with default credentials admin/framexx (all can be modified).

Go to System Menu-Status, check the current device IP address assignment and type in any browser in the command line IP_address:port (example 192.168.0.200:8080).

Login popup will appear to enter the credentials.

The Web interface contains 8 sections (see below).

The FrameXX device can be fully controlled via this Web interface.

This is the most pleasant style how to work with device internal memory (13GB free).

It is possible to update device with new firmware version located in PC, as well as to see real current screenshot from running device.



Section “Status”

The screenshot shows the FrameXX management console interface. At the top, there is a navigation bar with a back arrow, a globe icon, and the IP address 192.168.0.152:8080. Below this is a header with the FrameXX logo and the title "FrameXX management console". A menu bar contains the following items: Status (selected), Start slideshow, History, Create playlist, Settings, Timers, Local memory, and Update. The main content area displays "Status : in folder selection" and two buttons: "Sleep" and "Reboot". Below this is a section titled "FrameXX device information" with the following details:

Device name:	FrameXX-2-AC:DB:DA:39:A5:38
FrameXX account:	dipp06
IP:	192.168.0.152
Version FrameXX:	3.1.16
MAC address wifi :	04:E6:76:49:0B:1A
MAC address ethernet :	AC:DB:DA:39:A5:38
Next autoplay:	MEMORY - /satplst.plst

At the bottom of this section is a link labeled "Show preview".


Section “Start slideshow”

The screenshot shows the FrameXX management console interface for the "Start slideshow" page. The navigation bar is the same as in the previous screenshot, but "Start slideshow" is now selected. The main content area features a "URI :" label, a dropdown menu set to "LOCAL", and an empty input field. Below this is a "Recursive:" checkbox which is unchecked, and a "Start Slideshow" button. A row of buttons includes "MEMORY", "LAN", "FTP", "WWW", and "Dropbox". Underneath, it says "Example of URI input :" followed by a list of examples and their descriptions:

LOCAL SD /folder/test.plst	(start of slideshow from SD)
HTTP www.i-frame.net	(start of single web page)
FTP user:pass@ftp.i-frame.net/folder	(Slideshow from folder on FTP)
LOCAL USB1 /folder	(Slideshow from folder on USB)



Section “History”




The screenshot shows the 'FrameXX management console' interface. At the top, there is a navigation bar with buttons for 'Status', 'Start slideshow', 'History', 'Create playlist', 'Settings', 'Timers', 'Local memory', and 'Update'. The 'History' tab is currently selected. Below the navigation bar, the 'Title' section lists several items, each with a 'Start Slideshow' button to its right:

- MEMORY - /satplst.plst
- FTP - 70199 - ftp.i-frame.net //test/2
- MEMORY - /iFrame_video_short.mp4
- USB1 - /TEST/Video/Satplus
- MEMORY - /framexx/N_FTP_-_70199_-_ftp_i-frame_net__test_2
- http://webhosting.satplus.cz/test/_index9.html

Section “Create playlist”

This is very basic implementation, for operation with Playlists we strongly recommend to use Playlist wizard in CONTROL cloud.



The screenshot shows the 'FrameXX management console' interface with the 'Create playlist' tab selected. The 'Playlist creation:' section contains the following form fields:


- SlideShow item: [Text input field]
- Location : [Text input field]
- Recursive :
- Options:
- Delay : [Text input field] seconds
- Horizontal banner top: [Dropdown menu]
- Horizontal banner bottom: [Dropdown menu]
- Vertical banner left: [Dropdown menu]
- Vertical banner right : [Dropdown menu]
- RSS feed : [Text input field]
- Ordering : [Dropdown menu]
- Copy to local storage:
- Local storage location: [Dropdown menu] [Text input field]
- Transition : [Dropdown menu]
- Layout : [Dropdown menu]
- Reload :
- Reload delay : [Text input field] seconds
- Text speed : [Dropdown menu]

A 'CREATE' button is located at the bottom left of the form.



Section “Settings”

This section contains 5 subsections grouped by settings options.
Settings – Display options:




The screenshot shows the FrameXX management console interface. At the top, there is a navigation bar with buttons for Status, Start slideshow, History, Create playlist, Settings (which is active), Timers, Local memory, and Update. Below the navigation bar, the main heading is "View and change settings". Underneath, there is a list of settings categories: Display options, Banner options, File mask options, Advanced options, and Reporting/Monitoring. The "Display options" category is expanded, showing a table of settings:

Delay :	<input type="text" value="5"/>	seconds
Layout :	<input type="text" value="FULLSCREEN"/>	▼
Transition :	<input type="text" value="DISSOLVE"/>	▼
Background color :	<input type="text" value="Black"/>	▼
Aspect ratio :	<input type="text" value="DEFAULT"/>	▼
Ordering :	<input type="text" value="NAME"/>	▼

Below the table, there are buttons for "UPDATE" and "Banner options", "File mask options", "Advanced options", and "Reporting/Monitoring".

Settings – Banner options:



The screenshot shows the "Banner options" subsection of the settings. The "Banner options" category is expanded, showing a table of settings:

Horizontal banner top :	<input type="text" value="NONE"/>	▼
Horizontal banner bottom :	<input type="text" value="NONE"/>	▼
Vertical banner left :	<input type="text" value="NONE"/>	▼
Vertical banner right :	<input type="text" value="NONE"/>	▼
Text speed :	<input type="text" value="NORMAL"/>	▼
RSS feed :	<input type="text" value="http://rss.nytimes.com/services/x"/>	
Banner background color :	<input type="text" value="Black"/>	▼
Banner font :	<input type="text" value="Default"/>	▼
Banner font color :	<input type="text" value="White"/>	▼
Banner overlay :	<input type="checkbox"/>	
Banner size :	<input type="text" value="Size 0 (1:10)"/>	▼
Banner location :	<input type="text" value="Center"/>	▼

Below the table, there are buttons for "UPDATE" and "File mask options", "Advanced options", and "Reporting/Monitoring".



Settings – File mask options:

▸ Display options

▸ Banner options

▾ File mask options

Play Photos : Play Videos : Play WWW lists : Play playlists :

Date mask :

Date period : days

Fixed Date : (format as yyyy.MM.dd)

▸ Advanced options

▸ Reporting/Monitoring

UPDATE

Settings – Advanced options:

▸ Display options

▸ Banner options

▸ File mask options

▾ Advanced options

LAN server : - User

Pass - Domain

Ftp server : - User - Pass

Enable - Server : - Time (minutes after midnight)

Http Download :

WWW starts with :

WWW address :

Flickr : - Quality

Reload : seconds

Reload delay :

Music :

Autostart : Local storage location:

Copy to local storage:

Show numbering: Show progress folder selection: Show progress slideshow: Device identifier :

Web control : User - Pass

▸ Reporting/Monitoring

UPDATE



Settings – Reporting/Monitoring:

+ Display options

+ Banner options

+ File mask options

+ Advanced options

+ Reporting/Monitoring

Account :

Monitoring:

Remote control :

Reporting ftp server : Server name : - User - Pass

Delay between checks: seconds

Include files in remote control:

Socks proxy server : Server name : - Port :

- User - Pass

Section “Timers”

FrameXX management console

Status Start slideshow History Create playlist Settings **Timers** Local memory Update

View and add timers

Timer enabled :

Title

00:39 - 00:42 Every day MEMORY - /satplst.plst [Remove](#)

01:00 - 02:00 Every day MEMORY - /satplst.plst [Remove](#)

02:00 - 03:00 Every day MEMORY - /satplst.plst [Remove](#)

03:00 - 04:00 Every day MEMORY - /satplst.plst [Remove](#)

04:00 - 05:00 Every day MEMORY - /satplst.plst [Remove](#)

05:00 - 06:00 Every day MEMORY - /satplst.plst [Remove](#)

06:00 - 07:00 Every day MEMORY - /satplst.plst [Remove](#)

Timer ON : :

Timer OFF : :

Day schedule : ▼

SlideShow : History : ▼ Uri :

Recursive :

Device OFF :



Section “Local Memory”

It is possible to address any local storage location from the dropdown menu (MEMORY, SD, USB1).

Field “Location” can contain folder(s), if it does not exist then it will be created.

Once Copy procedure is completed, press “Refresh list” button to get current file listing.

The screenshot displays the FrameXX management console. At the top, there is a navigation bar with buttons for Status, Start slideshow, History, Create playlist, Settings, Timers, Local memory (selected), and Update. Below this, the 'Local memory' section is active. It features an 'Upload new file' area with a dropdown menu set to 'MEMORY' and a 'Location' input field containing '/'. There are buttons for '+ Add files...', 'Start upload All', and 'Cancel upload'. A note states: 'After upload it is needed to refresh the file list (F5)'. Below the upload area are buttons for 'Select All', 'Deselect All', 'Refresh list', and 'Delete all selected'. The main area shows a file list table with columns for file names and actions (Start and Delete).

File		Start	Delete
<input type="checkbox"/>	Root/main level	Start	Delete
<input type="checkbox"/>	iFrame_video_short.mp4	Start	Delete
<input type="checkbox"/>	Samsung LED Demo.mp4	Start	Delete
<input type="checkbox"/>	Syn_Czech .mp4	Start	Delete
<input type="checkbox"/>	earth_night_rotate_1080.mov	Start	Delete
<input type="checkbox"/>	World's First Wingsuit High Five.mp4	Start	Delete
<input type="checkbox"/>	Canon Bring Colour To life.mp4	Start	Delete
<input type="checkbox"/>	framexx	Start	Delete
<input type="checkbox"/>	framexx/N_FTP_-_70199_-_ftp_i-frame_net__test_2	Start	Delete
<input type="checkbox"/>	synology Inc.mp4	Start	Delete
<input type="checkbox"/>	world-china-bamboo-giant-eating-fresh-hd-wallpaper.jpg	Start	Delete
<input type="checkbox"/>	framexx/N_satplst_plst	Start	Delete
<input type="checkbox"/>	iFrame	Start	Delete
<input type="checkbox"/>	iFrame/N_FTP_-_70170_-_ftp_i-frame_net__REKLAMY	Start	Delete
<input type="checkbox"/>	FE magazin_2015_02-upc.mpg	Start	Delete
<input type="checkbox"/>	SvetloZdravi_AkceHimalajeUP.mpg	Start	Delete

Section “Update”



Status

Start slideshow

History

Create playlist

Settings

Timers

Local memory

Update

Update iframe.apk

10. Remote access – CONTROL cloud

This is the most universal remote control. This remote access can be accomplished in (almost) any network. The device just requires basic internet access for download. This feature preserves secure access into local network as framexx device uses only communication out and therefore it is not needed to open ports on a router (or firewall). This work well even for large corporate installations.

The communication is processed via independent ftp server. When set as Default, the device is using FrameXX system server. However, framexx can be configured to communicate with any FTP server.

Note: if remote communication is forwarded to other FTP server, be sure the server supports an unlimited number of simultaneous accesses as some basic public FTP servers have a limit of a few connections (1-5) which prevents proper framexx remote communication.

Because the communication is based on full configuration XML file, (almost) a full set of device commands is supported and it is possible to change any device parameter.

The Remote access relies on **Remote control** Settings in Options.

The device is operating according to the XML configuration file located on FTP server and is checking it in regular intervals. This interval can be set in **Remote control interval** parameter (default 30 sec), and this current value is longest interval between new commands on CONTROL cloud and processing in the device.

CONTROL cloud main features:

- Centralized monitoring and administration facilities
- Remote control
- Control of individual devices and groups
- Creating playlists (Drag and Drop)
- Remote settings (even detailed device parameters and groups)
- Full-screen presentations archiving
- For greater safety, possibility to use of private FTP server for device management and display content



- 2 levels of access – FREE (includes basic settings and device status), PRO (full functionality)
- One time fee for obtaining a license, the license is transferable to any device (the number of active licenses corresponds to the number of devices with full access at any given moment, the license can be transferred between devices)

Differences between FREE and PRO license type:

FREE x PRO features comparison table		
	FREE	PRO
Basic surveillance overview of all devices/groups from one account	✓	✓
Basic device settings (Device ON/OFF, Restart, Stop Slideshow, Transition, Delay, Remote control interval, Start Slideshow from History, Start Slideshow from command line)	✓	✓
Advanced device settings (90% of all full local settings, Timers, Start Slideshow with files in the device (browse), Start Slideshow from FTP, Copy file(s) to device, Delete file(s) in device, Delete folder(s) in device, Create folder(s) in device)	✗	✓
Playlist creation wizard on assigned FTP server	✓	✓
Device assignment into groups, working with groups	✗	✓
General history view	✓	✓
Detailed history view with export	✗	✓

Basic view of all devices / groups from one account

The screenshot displays the FrameXX CONTROL interface with the following annotations:

- 1:** Next refresh button (circular arrow icon)
- 2:** Device status (red dot)
- 3:** Device name (Blue TV)
- 4:** Device icon (TV)
- 5:** Last record (In group: 1)
- 6:** Folder (MEMORY - camera)
- 7:** Folder name (MEMORY - camera)
- 8:** File name (379344101_0f8a4f8a_x.jpg)
- 9:** Delay/Items (5/4)
- 10:** Device icon (TV)
- 11:** Settings menu (gear icon)
- 12:** Settings icon (gear icon)
- 13:** Device name (Blue TV)
- 14:** Delay/Items (5/4)
- 15:** Settings menu (gear icon)

1. Counter to next device status refresh (according to User profile settings – interval). It is possible to refresh the list anytime – click



- on “Next refresh” or to use browser refresh from cache (F5), eventually full browser refresh (Ctrl+F5)
2. Single devices can be grouped into groups. Then, you can send commands to all devices contained in this group.
 3. Here it is possible to enter LOG files from all completed Slideshows
 4. If device is running and has PRO license active, you can access current Slideshow LOG
 5. Exact information, when last Slideshow has been terminated (red symbol – Slideshow not running) or what time it has been started (green symbol – Slideshow running)
 6. Folder of the last Slideshow (red symbol – Slideshow not running) or folder of current Slideshow (green symbol – Slideshow running). Folder appears only when Slideshow uses folder, for example web presentation (WWW) does not use folders, therefore field is empty
 7. Symbol if Recursion flag is active (Recursion is playing of complete folder structure, not only main folder)
 8. Last file from the last Slideshow (red symbol – Slideshow not running) or current file (it is affected by refresh interval settings) of current Slideshow (green symbol – Slideshow running).
 9. Current Delay (for images it is the period of exposition till the next image transition, for website refresh period, it does not effect for video) and total number of items in Slideshow
 10. FREE or PRO symbol of current license
 11. Device remote control. Device must have enabled remote control (and monitoring) and must use identical FTP remote control settings as in current JFrameXX account. Orange colour button=running device or running recently, Grey color=device operating in the past with possibility of being remotely controlled (no guarantee device is connected at this moment)
 12. Enter to Options – device/group management, licensing (explained further)
 13. Back to current device list view – the list is always processed (not from cache), therefore the view is refreshed and corresponds to current moment
 14. Enter to Playlist wizard. *Note – when FTP remote server defined as Default, Playlist wizard is not supported (the reason is shared system storage space, therefore all users would share all data which is not acceptable).*
 15. User account settings, log-out.

Basic settings of individual devices / groups



There are 2 control levels of device remote control – Basic and Advanced (it requires PRO license).

As a common condition, controlled devices must have Remote control enabled (in Monitoring / Remote control / Proxy) and properly configured (either keep “default” value or define own ftp server – this must be in accordance with FrameXX account settings).

The screenshot shows the 'CONTROL (remote control)' interface for a device named 'FrameXX-MUA-2-M'. At the top left is the FrameXX logo. Below it, a green button labeled 'Send to FrameXX' is marked with a green '1'. The main settings area includes: 'Device status: On' with a green '2' next to it; 'Device mode change: No change' with a dropdown arrow and a green '3'; 'Time zone: GMT+02:00' with a green '4'; 'Transition: DISSOLVE' with a dropdown arrow; 'Delay (hh:mm:ss): 0:0:5' with three spinners; and 'Remote control interval (hh:mm:ss): 0:0:20' with three spinners. Below this is a 'Slideshow' section with a 'Slideshow:' input field, a 'Recursion' checkbox, and an orange 'History' button marked with a green '5'. At the bottom of the interface is another green 'Send to FrameXX' button marked with a green '1'.

1. Button that sends current settings to the device. This button is placed in 2 locations (top, bottom) and has identical functionality
2. Device Status. As the colour of the Settings button in Basic view may not exactly reflect current device status, here it is possible to find out an exact information



3. Here it is possible to change current device status from the following options:
 - No change (default, it is expected that sent commands change device settings not device mode)
 - DEVICE ON (device will be ON, regardless of what the current mode is)
 - DEVICE OFF (sleep) – Device will be in sleep mode. Sleep mode is special mode when the device has HDMI output off (therefore it allows the preconfigured monitor to enter standby mode), but it is operating in basic mode with Wifi/LAN/IrDA enabled, therefore it is possible to restart device (locally, remotely) anytime.
 - Restart – Device will be restarted (if device autostart is defined then Slideshow can be started automatically after restart)
 - Stop Slideshow – Device will return to basic file selection screen.
4. Time zone is a very important parameter ! Time zone must be identically set in the device as well as in FrameXX account settings. If not, then red warning message will be displayed here and it is recommended to adjust the Timezone immediately, otherwise the Time information during the Slideshow (and in History) may be not correct.
5. Start Slideshow command line can be entered manually or it is possible to use menu and select Slideshow from device history (already completed Slideshows).


Advanced settings of individual devices / groups

Advanced settings appear with devices that have PRO license level enabled (a 20-digit unique code is required).

There are a lot of settings (number of supported functions varies according to current implemented features in the device), but the goal is to support a full set of functions available locally in the device via menu.


For exact descriptions of these functions, please follow Chapter #8, Settings.

Significant difference is in command window (located in bottom).



Here it is possible to define Timers, command file operations (Delete, Copy) and select files from FTP server and from any local device memory (MEMORY,USB,SD).

COPY-DELETE




It is possible to
Delete File
Delete Folder
Create Folder
Copy

All functions are working with local device memories, here it is possible to fully control the files remotely within the device.
A Location can be used by any local memory, i.e. MEMORY, USB1, (USB2) or SD.

Command can contain either folder (copy all files, optionally with Recursion flag – as well full subfolder structure) or individual files.

Commands can be combined, therefore it is possible to simultaneously send any number of various commands (for example 1xDeleteFile command, 2xDeleteFolder command and 3xCopy commands...)

TIMERS



The FrameXX device supports an unlimited number of Timer events.
Each Timer definition can carry separate parameters, these are:



1. Slideshow
2. Slideshow can be selected from Device History, from any device local memory or from assigned FTP server
3. Slideshow can carry Recursion flag (playback of all subfolders)
4. Each Timer event can be defined according to the Time interval and Day scenario (when Timer is valid). There are the following Day scenarios supported
 - Every day
 - Working days (Monday-Friday)
 - Working days (Monday-Saturday)
 - Working days (Sunday-Thursday)
 - Working days (Saturday-Thursday)
 - Weekend (Saturday-Sunday)
 - individual days (Mo-Su)

Working with Playlists, creating, editing

The CONTROL cloud with enabled PRO license contains a Playlist wizard. With this wizard it is possible to simply create your own playlist (extension plst) – exact Playlist description – see Chapter #11.

Please note, it is required to use your own FTP server settings in FrameXX account. If using “Default” value, then the system FTP server is used and for security reasons (sharing of identical server space) it is not allowed to use Playlist wizard.

Playlists


+ Add playlist

MujplaylistTest1	Change Remove
SPORT	Change Remove
TTplst	Change Remove
TV23	Change Remove
Testfotovideo	Change Remove




In the main Playlist window it is possible to start with new Playlist or to modify any existing.

Playlist wizard offers following options:



1. Pictures, videos (files) located on assigned private FTP server. You can use Drag&Drop to move item into the playlist.
2. Once an item is moved into the playlist, there are set basic predefined values. All these item values can be modified, each playlist item can hold different individual settings
3. Replication button – it doubles the current playlist item in playlist
4. Delete button
5. The CONTROL FTP user interface contains a very simple FTP client. It is possible to create a New folder on FTP and organize files accordingly
6. It is possible to upload new files to FTP server. Please note, this is simple FTP interface, therefore it is recommended for big file uploads to use a separate FTP client (as there you can get a lot of other features, e.g. file upload resume, multiple upload optimization etc..)
7. The Playlist contains global parameters valid within current playlist (overridden by separate parameters in each line). These parameters, as well as playlist name can be edited here.
8. Once completed, Save playlist to FTP server.





History of presentations in the device

One of the most important features is the ability to review finished activity of devices. All Slideshow are creating the History records (LOGs) and these records can be evaluated later.

There are 2 levels of History records – Basic and Detailed (available with PRO license).

Basic History

Device - FrameXX-showroom

5 From: 04.03.2015 To: 11.03.2015 6

Date	Start	End	Folder	Items displayed	Delay	Recursion	Firmware	
11.03.2015	13:23	13:24	MEMORY -/initials	17	5		3.1	Remove LOG
11.03.2015	13:11	13:23	MEMORY -/	22	5		3.1	Remove LOG
11.03.2015	13:10	13:11	MEMORY -/initials	7	5		3.1	Remove LOG
11.03.2015	12:30	13:10	MEMORY -/	212	5	Δ	3.1	Remove LOG
11.03.2015	10:00	12:00	MEMORY -/	569	5	Δ	3.1	Remove LOG
11.03.2015	09:00	10:00	MEMORY -/	314	5	Δ	3.1	Remove LOG
10.03.2015	16:15	17:00	MEMORY -/	214	5	Δ	3.1	Remove LOG
10.03.2015	15:30	16:00	MEMORY -/	139	5	Δ	3.1	Remove LOG
10.03.2015	14:47	15:15	MEMORY -/	134	5	Δ	3.1	Remove LOG

1. Enter to Detailed LOG view (PRO license)
2. Total number of displayed items within Slideshow
3. Recursion flag in the Slideshow



4. Device firmware version at the time when Slideshow has been running
5. Selected period – it is possible to define the period windows to limit the number of displayed History records
6. All History records can be exported to general text log file

Detailed History

Here all detailed information is available not just about presented items (date, time HH:MM, seconds optional), and filename, but as well as complete Slideshow settings.

This History level can be used as confirmation for Slideshow expositions for business case reports, for example.

Device - FrameXX-showroom - dixx06#FrameXX-showroom#98:3b:16:fc:f9:a3#5#13:23#11:03:15.log

Date: 11.03.2015	Start: 13:23	End: 13:24
Folder: MEMORY - /animals	Numbering: YES	Time zone: GMT+01:00
Delay: 5	Refresh interval: NO / 60	Firmware: 3.1
Order: ALPHABETIC	Autostart: NO	Total slides: 4
Transition: DISSOLVE	Recursion: NO	
Layout: FULLSCREEN	Language: cz	


11.03.2015 13:23	2784868500_dc2e671e64_o.jpg
11.03.2015 13:23	2879932238_267cd3bc05_o.jpg
11.03.2015 13:23	2958307859_0ba307879c_o.jpg
11.03.2015 13:23	3379344109_4f08a44faa_o.jpg
11.03.2015 13:23	2784868500_dc2e671e64_o.jpg

Options – device/group management, licensing

This option (item#12 from basic view) enables the definition of new groups, assigning/removing devices to/from group, as well as assigning and changing License codes.

Once everything is done, press Finish to save all the changes and return back to Basic view window.






Assigning of new License code



Removal of License code (possible transfer to FREE device)



New device assignment into group (can be selected only if device has current PRO license)



11. Playlist usage

The PLAYLIST file can be manually started from a list of files or run with other files with the Start Slideshow button.

There is even possible to start a PLST file automatically upon USB or SD memory insertion (if filename of PLST is "autorun.plst").

PLST is line structured text file where each line represents individual PLST item with separate options.

A PLST file is processed in the following 3 phases:

- 1) 1st phase – PLST file accepts all current settings from device
- 2) 2nd phase – PLST looks into general PLST section – HEADER – where are located common parameters are located for all PLST items
- 3) 3rd phase – PLST processes every line and sets appropriate parameters for this item. These parameters are valid just for the specified line.

Next line is processed again from the 1st phase

Parameters are separated with “,” symbol

Parameters are not case sensitive

Comments (not functional lines) begin with symbol "#"

HEADER: – section with general settings form PLST file plst

SI: (Slideshow Item) – each functional line line must begin with “SI:”

SD, USB1, USB2, Memory – local storage.

Can be used as well relative path current to PLST folder, e.g. SI:

Subfolder/123.jpg

FTP remote location – <ftp.FrameXX.net/123.jpg> or with credentials

<ftp://username:pasword@ftp.FrameXX.net/123.jpg>

WWW remote location – <http://www.cnn.com> or www.cnn.com

STREAM remote location (when rtcp stream requested) –

Stream://www.stream.net

Example of plst file

HEADER,D:10, LAYOUT:FULLSCREEN, NUMBER:FALSE, SILENT:ON,

HB:NONE, VB:NONE, TRANS:DISSOLVE, TXIM_NAME : IF-

show,TXIM_LOCATION: SD/iFrame

SI:ftp://70199:70199@ftp.FrameXX.net/ds-13.jpg,,HB:info, VB:IMAGE

SI:http://www.FrameXX.net

SI: FolderA/23.jpg



identical location as PLST file, one folder deeper)

SI: USB1/iFrame/ABC.jpg, , ar:zoom, VB:image

SIPREF:stream://212.79.96.134:8015, TIM:30, D:300

This video stream will start repeatedly at reaching 30mins (12:30, 13:30 - according system time) and # playback will last 5 minutes (300 sec)

KEY	AVAILABLE PARAMETERS	DESCRIPTION	EXAMPLE
D	<number in seconds>	delay to the next photo (in seconds), duration	D:20
HBT	NONE, TEXT, IMAGE, CLOCK, INFO	Horizontal banner top)	
HBB	NONE, TEXT, IMAGE, CLOCK, INFO	Horizontal banner bottom)	
VBL	NONE, TEXT, IMAGE, CLOCK, INFO	Vertical banner left)	
VBR	NONE, TEXT, IMAGE, CLOCK, INFO	Vertical banner right)	
TXIM_NAME	<filename without extension, expected *.txt for TEXT and *.jpg for IMAGE>	name of the identifier used to retrieve image or text file to be used in a banner,no extension needed, only file name)	
TXIM_LOCATION	<path for location>	location where the image or text file for the banner can be found)	TXIM_LOCATION:src TXIM_LOCATION:fbp TXIM_LOCATION:US TXIM_LOCATION:ME
BLOC	TOP_LEFT, CENTER, BOTTOM_RIGHT	IMAGE or CLOCK position within banner	
BSIZE	<number in 00's corresponding to Size>	banner size	BSIZE:300 (identical a
BTC	BLACK, BLUE, DARK_GRAY, GRAY, GREEN, LIGHT_GRAY, MAGENTA, RED, WHITE, YELLOW	banner text color	
BOS	FALSE, TRUE	banner overlay	
BBG	BLACK, BLUE, DARK_GRAY, GRAY, GREEN, LIGHT_GRAY, MAGENTA, RED, WHITE, YELLOW	banner background	
TEXT	VERY_SLOW, SLOW, NORMAL, FAST, VERY_FAST	Speed of crawling text (if text longer then screen width)	
ORDER	RANDOM, NAME, TIME, PATH	Files order within Slideshow	
COPY	FALSE, TRUE	false/true if the files should be copied first	
COPYLOC	<path for local location - cache>	Location to copy before Slideshow starts	COPYLOC: MEMORY/f
TRANS	DISSOLVE, FADE_IN_OUT, ZOOM_IN, ZOOM_OUT, SLIDE_LEFT, SLIDE_RIGHT, RANDOM, NO_TRANSITION, #KEN_BURNS_ZOOM_OUT, GRAY_SCALE, PAGE_TURN, BLINDS	Transition type between pictures	
LAYOUT	FULLSCREEN, FOUR_REGIONS, FOUR_REGIONS_CENTERED, RANDOM, CORNERS, SINGLE_FLY, DOUBLE_FLY, RANDOM_FLY, FLY_DOWN, FLY_UP, MAX	Current Slideshow layout	
R	TRUE, FALSE	Find photo also in subfolders (not effective in HEADER)	
AR	DEFAULT,STRETCH,ZOOM	Aspect ratio of the image	



12. Special system files

IFR STRUCTURE

.ifr file allows operation with Memory (Memory can be controlled also via local Web access)

Parameters are not case sensitive

This file can be manually started from filelist or automatically started upon USB/SD insertion (if filename is "autorun.ifr"). Processed is according to the following syntax (XML file):

```
<autocopy>
```

```
<copy from="USB1/Av" to="MEMORY/Averia/" DeleteBeforeCopy="true"/>
```

```
<start location="MEMORY/Av"/>
```

```
<delete location="MEMORY/Av"/>
```

```
</autocopy>
```

```
<autocopy></autocopy> obligatory start /end
```

```
<Copy from="Source" to="Destination" DeleteBeforeCopy="true" Recursion="true"> if
```

```
DeleteBeforeCopy or Recursion not present then no Destination delete accomplished and no Recursion
```

```
<Start location="Storage_path"/> where is Slideshow immediately started from
```

```
<Delete location="Storage_path"/> deletes any file or folder
```

WWW STRUCTURE

Simple ASCII file with list of www pages (1line=1URL). Processed with current system Delay, therefore repetition of URL address causes refresh of web page. For Windows users - using Notepad.exe in Windows requests Saving with ANSI Code page, otherwise there will be some added reserved bytes in the header of the file (Unicode, UTF-8), which could cause problem in the processing of the first line. Save with *.* mask, otherwise there will append .TXT in filename (LIST.WWW.TXT) which the device cannot recognize.



www.asc.com

<http://www.123.com>

<http://www.123.com>





13. HOME – manual monitor adjustment



- ① **[POWER] button**
Press to switch the display on or off.
- ② **[INPUT] button**
Press to select input source.
- ③ **[MENU] button**
Press to access the OSD menu.
- ④ **[▲] button**
Press to move the highlight bar up to adjust the selected item while OSD menu is on.
- ⑤ **[▼] button**
Press to move the highlight bar down to adjust the selected item while OSD menu is on.
- ⑥ **[+] button**
Press to increase the adjustment while OSD menu is on, or to increase the audio output level while OSD menu is off.
- ⑦ **[-] button**
Press to decrease the adjustment while OSD menu is on, or to decrease the audio output level while OSD menu is off.

Default settings



14. Limited warranty

As the original purchaser of this product, you receive these warranties from Kobe s.r.o..

Your FrameXX (hereafter referred to as “Device”) will be free from defects in material and workmanship and will perform in substantial compliance with your user documentation accompanying Device for one year from the purchase date providing proper use of Device.

Any unauthorized or improper use of Device may cause your warranty to become void.

Disclaimer

This limited warranty is the only warranty Kobe s.r.o. makes for Device. To the extent allowed by Law, no other warranty applies, whether expressed, implied, or statutory, including any warranty of merchantability, of fitness for a particular purpose, or of non-infringement. This warranty does not cover accidental damage, wear and tear, or consequential or incidental loss. Under no conditions is Kobe s.r.o. liable for loss of or damage to, a computer; nor loss of, or damage to, programs, records, or data; nor any consequential or incidental damages, even if Kobe s.r.o. has been informed of their possibility.

